

Installation Instructions RDB\60\1.4 Detachable gate Barrier

1. Form 2 No. Neat foundation holes 500mm deep x 400mm wide at 1.4m centres.
2. Place barrier feet in holes on 100mm of medium grade stone chippings ensuring both feet are parallel and the lids are on same side.
3. Place barrier in feet and lock in position.
4. Fill holes with 4/2/1 mix concrete to form 500mm deep x 400mm wide foundation, trowel finish upper surface to shed water, or tamp finish to receive decorative surfacing.
5. Check operation of lock and that barrier will lift out freely. Adjustment can be made by repositioning of barrier feet until an easy operation is achieved.
6. Leave barrier in locked position for a minimum of 24 hours.

WARNING

FAILURE TO COMPLY WITH THESE INSTRUCTIONS MAY CAUSE MALFUNCTION OF THE BARRIER AND INVALIDATION OF YOUR WARRANTY. PLEASE ADHERE TO THEM.

